

POPUPTENT

10' x 10' & 10' x 20'

SETUP INSTRUCTIONS

EASY UP STYLE TENTS ARE INTENDED AS A SHADE SOLUTION AND ARE NOT RECOMMENDED FOR INCLEMENT WEATHER.

STEP 1

Remove the popup tent from the transport bag and the rope tie downs from the outer pocket of the transport bag.

STEP 2

Stand the canopy frame upright in the center of the desired set-up location.

NOTE: Ensure there are no low laying branches, overhangs, or other obstacles above the setup area.

STEP 3

Gently pull the outer frame legs partially extended with a second person assisting on the opposite side.

STEP 4

Lift the frame into position by expanding the truss bars until the frame is fully extended. Be careful not to pinch fingers or hands as you lift and step backwards slowly.

STEP 5

Now that the frame is fully extended, lock the top bracket sliders into place at each corner by holding the frame with one hand and pulling the slider in place until it locks.

STEP 6

Adjust the frame legs to your desired height by lifting each leg and slowly pulling out the inner leg until it pops into place. Repeat this process by using the pull and pin process for each leg.

STEP 7

Placing one foot on each corner footpad and slowing extending each leg into place can also extend the frame legs.

STEP 8

Attach U-Clips to each side of the canopy to secure the canopy top.



PARTY RENTAL

CORT Party Rental

cortpartyrental.com

877.939.7368

SKU 27474

INCLUDES

10' x 10' Popup Tent
(4) 30 lb Rubber Base Weights
(4) Tent Rope Tie Downs
Transport Bag

SKU 27475

INCLUDES

10' x 20' Popup Tent
(6) 30 lb Rubber Base Weights
(6) Tent Rope Tie Downs
Transport Bag

OPTIONS

10' Popup Tent Wall



POPUPTENT

10' x 10' & 10' x 20'

SETUP INSTRUCTIONS

STEP 9

Attaching weights to the tent: Begin by placing the rubber base weights upright, on the inside of each tent leg.

STEP 10

Standing under the tent, facing a leg, take the free end (non-loop end) of a rope tie down (rope) and pass it behind the leg and through the loop end, pulling tight and ensuring it is above the frame crossbars.

STEP 11

Pass the end of the rope through the rubber base weight, around the leg then back through the rubber base weight again and tie off.

STEP 12

Continue these steps for each leg on the tent.
10' x 10' Pop up Tent = 4 legs
10' x 20' Pop up Tent = 6 legs



PARTY RENTAL

CORT Party Rental
cortpartyrental.com
877.939.7368

SKU 27474

INCLUDES

10' x 10' Pop up Tent
(4) 30 lb Rubber Base Weights
(4) Tent Rope Tie Downs
Transport Bag

SKU 27475

INCLUDES

10' x 20' Pop up Tent
(6) 30 lb Rubber Base Weights
(6) Tent Rope Tie Downs
Transport Bag

OPTIONS

10' Pop up Tent Wall



POPOP TENT

10' x 10' & 10' x 20'

BREAKDOWN INSTRUCTIONS

STEP 1

Untie the rope from each rubber base weight and remove the rope from each corner/leg of the tent. Place the tie downs in the front pocket of the transport bag.

STEP 2

Detach U-clips from each side of the canopy frame.

NOTE: Detaching the clips must be done **first**, before closing the frame of the tent.

STEP 3

Release each pull pin on each leg and shorten the frame to its original height prior to extending the legs during the setup process.

STEP 4

Disengage the locking button at each corner of the frame and pull the slider down slowly until the button is completely free of the slider.

STEP 5

Hold the middle frame section with a second person assisting on two sides of the frame.

STEP 6

Walk forward slowly for frame to fold inward and close. Be careful not to pinch fingers or hands as you close the frame.

STEP 7

Completely fold the frame securely and place into the unzipped storage bag by sliding it down into the bag slowly until the canopy fits comfortably. Zip the storage bag completely shut.



PARTY RENTAL

CORT Party Rental
cortpartyrental.com
877.939.7368

SKU 27474

INCLUDES

10' x 10' Popup Tent
(4) 30 lb Rubber Base Weights
(4) Tent Rope Tie Downs
Transport Bag

SKU 27475

INCLUDES

10' x 20' Popup Tent
(6) 30 lb Rubber Base Weights
(6) Tent Rope Tie Downs
Transport Bag

OPTIONS

10' Popup Tent Wall

