MOBILE BANQUET CABINET 2 DOOR

SETUP INSTRUCTIONS

STEP 1

Secure the unit on a **flat surface**.

STEP 2

Plug the electrical cord in to your power source with a 3-prong grounding receptacle

STEP 3

If humidity is desired, add hot water to a pan and place on the bottom of the unit. If dry heat is desired (no humidity) do not add a pan of water.

STEP 4

Pre-heat the cabinet. Adjust the air temperature (heat) control dial to desired setting. Allow approximately **15 – 30 minutes** for the unit to pre-heat.

STEP 5

When the yellow light goes off, the unit has reached the desired temperature.

SHUTDOWN INSTRUCTIONS

STEP 1

Unplug the unit from the power source.

STEP 2

Allow the unit to cool then remove the pan of water if used as well as excess food or debris and secure the unit.

TROUBLESHOOTING

CABINET DOES NOT GET WARM

- ✓ Confirm the electrical cord is properly plugged into your power source with a 3-prong grounding receptacle and the unit is set to the **on** position.
- ✓ Ensure the power source supports 120 volts of power.
- ✓ Check and reset your circuit breaker.

CORT PARTY RENTAL

CORT Party Rental
cortpartyrental.com
877.939.7368

SKU 13734
INCLUDES
Mobile Banquet Cabinet
3 Shelves

NOTES
Extension cords may lower power current and not allow the oven to run properly. Power requirements: 120 volt, 9 amps, 1050 watts.

The yellow indicator light will continue to go on and off as the thermostat cycles.

The door should be kept tightly closed during pre-heating to obtain the optimum environment.

Holds (96 - 120) 11" covered plates, stacked four high.