

ELECTRIC COMMERCIAL REFRIGERATOR

SETUP INSTRUCTIONS



PARTY RENTAL

CORT Party Rental

cortpartyrental.com

877.939.7368

STEP 1

Secure the unit on a **flat surface**.

STEP 2

Plug the electrical cord into your power source with a 3-prong grounding receptacle.

STEP 3

Inside the unit, turn the temperature control knob to the desired setting.

STEP 4

Allow at least **4 to 6 hours** for the unit to completely reach cold temperatures. The range is 32 to 44 degrees Fahrenheit. Review the thermometer to verify your desired temperature has been reached.

SKU 6965

INCLUDES

Commercial Refrigerator

3 Shelves

OPTIONS

Full Size Sheet Pan 18" x 26"

Half Size Sheet Pan 18" x 13"

NOTES

The unit must always remain in an upright position.

Extension cords may lower power current and not allow the unit to run properly.
Power requirements: 120 volt, 5 amps, 600 watts.

This unit functions best if plugged into an adequate power source **24 hours** in advance of the desired use.

Each unit includes three adjustable shelves and is designed to operate in general indoor temperatures.

VIDEO LINKS

Setup/Shutdown:

<https://youtu.be/lwSJQsygwkk>

Troubleshooting:

<https://youtu.be/bze48FSpM4M>

ELECTRIC COMMERCIAL REFRIGERATOR TROUBLESHOOTING

UNIT DOES NOT TURN ON

- ✓ Check the circuit and reset or use another dedicated outlet.
- ✓ Check thermostat setting.
- ✓ Ensure the plug to the power cord is properly plugged into the outlet and that your power source supports 120 volts of power.

UNIT RUNS TOO MUCH OR TOO LONG

- ✓ If the room or space is hot, it's normal for the unit to run longer in higher temperatures.
- ✓ Warm food will cause the unit to run more to reach desired temperatures.
- ✓ Frequent opening of the door will result in added run time.
- ✓ Check the thermostat, it may need to be adjusted to a warmer setting.

INTERIOR TEMPERATURE IS TOO WARM

- ✓ Check the thermostat, it may need to be adjusted to a colder setting.
- ✓ Frequent opening of the door will result in warmer temperatures.

EXTERNAL SURFACE IS WARM

- ✓ This is normal while the compressor works to transfer heat from inside the appliance cabinet.

CORT[®] PARTY RENTAL

CORT Party Rental

cortpartyrental.com

877.939.7368

SKU 6965

INCLUDES

Commercial Refrigerator

3 Shelves

OPTIONS

Full Size Sheet Pan 18" x 26"

Half Size Sheet Pan 18" x 13"



VIDEO LINKS

Setup/Shutdown:

<https://youtu.be/lwSJQsygwkk>

Troubleshooting:

<https://youtu.be/bze48FSpM4M>